



# ZTE Mobile Hotspot



## To enable Hotspot

- Press and hold the Power button until you see the **Welcome screen**.
- Wait 15 seconds.
- Short press the **Function** button twice, then press Power button once to obtain the Wi-Fi password (password is also on back of Hotspot)
- Press **Power** button again to go back to **Welcome** screen.

## To connect your device to the Hotspot's Wi-Fi

- Go to your device's Wi-Fi  setting and make sure that Wi-Fi is turned on
- Select "**SprintHotspot...**" from the list of available networks
- Type in the password (on back of Hotspot)

## To turn off Hotspot (always turn off when not in use)

- Press and hold the **Power** button for a few seconds until the screen goes black.

## To charge Hotspot

- Check to see if the Hotspot is charged by looking at the battery icon on the top right of the screen.
- If it isn't fully charged, plug the cable into the Charging Port and to any electrical outlet.
- **IMPORTANT:** Do not leave Hotspot plugged into outlet or overcharge device.  
**Remove from outlet once it is fully charged.**

## Tips to maximize Internet browsing speed:

- Place the Hotspot in a location where signal strength is strongest (e.g. near a window)
- Keep it at least 4-6 feet away from electrical devices such as cell phones, cordless phones, TVs and microwaves
- Keep it in a clear open space for best signal reception
- Connect as few devices to the Hotspot as is necessary
- Power the Hotspot off when it is not being used

*Need further assistance? Call the library at 412-882-6622 or send an email to [slimonl@einetnetwork.net](mailto:slimonl@einetnetwork.net)*